






HUB CAPS

	PART NO.	SIZE	REPLACES
	Die Cast Use 9024-1 Gasket 9024	6 - Hole	Stemco 340-4024
	Die Cast Grease Version Use 9024-1 Gasket 9024G		Stemco 342-4024
	Die Cast With Side Plug Use 9024-1 Gasket 9024P	4-1/2" B.C.	Stemco 343-4024
	Die Cast Use 9042-1 Gasket 9042	6 - Hole	Stemco 340-4042
	Die Cast With Side Plug Use 9042-1 Gasket 9042P	5-1/8" B.C.	Stemco 343-4042
	Die Cast Use 9008-1 Gasket 9008	5 - Hole	Stemco 340-4013
	Die Cast Grease Version Use 9008-1 Gasket 9008G		Stemco 342-4013
	Die Cast With Side Plug Use 9008-1 Gasket 9008P		Stemco 343-4013
	Stamped Steel Use 9008-1 Gasket 9008S	5-1/2" B.C.	
	Die Cast Use 9018-1 Gasket 9098	6 - Hole	
	Die Cast With Side Plug Use 9018-1 Gasket 9098P	5-1/2" B.C.	
	Die Cast Use 9018-1 Gasket 9095	6 - Hole	Stemco 340-4095
	Die Cast With Side Plug Use 9018-1 Gasket 9095P	5-1/2" B.C.	Stemco 343-4095

Copyright 2005 Sirco Industries, Inc.